

Quick Start

(E-III iButton Keypad None Software Lever lockset)

The Eternity III lock uses four AA alkaline batteries. Install batteries into the battery holder. Plug the cable to the connector below the battery holder and the lock will beep once. To set the lock back to factory default setting, press and hold the reset button (Below the battery hold next to the power connector) about 10 seconds and the lock will beep twice. The manufacture default master code is **123456**. An index number is a sequential number (from 001 to 299) that is automatically generated by the Lock Processor. Please keep a record of all the index numbers and associate user codes and /or iButtons, so it can be utilized in the situation where a single or multiple user code and /or iButton need to be disabled.

Important: Failure to follow the exact procedure can result in erratic lock behavior.

- Set new Master Code

#	123456	#	11	#	1-6 Digits	#	1-6 Digits	#
(Default master Code)		(Function code)		(Enter New Master Code)		(Reenter New Master Code)		

- Enter Program Mode

#	1-6 Digits	#
(Enter Current Master Code)		

Note: You have to in the Program Mode to perform functions 1 – 29 below.
(Red LED flashing when lock is in Program Mode)

1. Set Date / Time

88	#	YYMMDDHHmm	#
----	---	------------	---

Note: Time format: [YEAR][MONTH][DAY][HOUR][minute]

2. Enter one User code with no restriction

01	#	1-8 Digits	#	#	#
(Enter User Code)					

3. Enter one iButton key with no restriction

01	#	iButton Key	#	#
(Touch the iButton reader on the lock)				

4. Enter one iButton key + User Code with no restriction

01	#	iButton Key	#	1-8 Digits	#	#	#
(Touch the Reader)			(Enter User Code)				

5. Enter multiple User codes with no restriction

01	#	1-8 Digits	#	#	#	1-8 Digits	#	#	#	...	1-8 Digits	#	#	#
(Enter 1 st User Code)					(Enter 2 nd User Code)					(Enter last User Code)				

6. Enter multiple iButton keys with no restriction

01	#	iButton Key	#	#	iButton Key	#	#	...	iButton Key	#	#
(Touch 1 st iButton)			(Touch 2 nd iButton)			(Touch last iButton)					

7. Enter one User code with time restriction

01	#	1-8 Digits	#	YYMMDDHHmm	#	YYMMDDHHmm	#	
		(Enter User Code)			(Enter starting Date/Time)			(Enter Ending Date/Time)

8. Enter one iButton key with time restriction

01	#	iButton Key + YYMMDDHHmm	#	YYMMDDHHmm	#
		(Touch iButton key on reader and enter starting Date/Time)			(Enter Ending Date/Time)

9. Enter multiple User codes with time restriction

01	#	1-8 Digits	#	YYMMDDHHmm	#	YYMMDDHHmm	#	...
		(Enter User Code)			(Enter starting Date/Time)			(Enter Ending Date/Time)

10. Enter multiple iButton keys with time restriction

01	#	iButton Key + YYMMDDHHmm	#	YYMMDDHHmm	#	...
		(Touch iButton key on reader and enter starting Date/Time)			(Enter Ending Date/Time)	

11. Disable one User (code or iButton)

02	#	3 Digits	#
		(Enter Index Number)	

12. Disable multiple Users (codes or iButtons)

02	#	3 Digits	#	3 Digits	#	...	#
		(Enter 1 st Index Number)			(Enter 2 nd Index Number)		

13. Enable one User (code or iButton)

03	#	3 Digits	#
		(Enter Index Number)	

14. Enable multiple Users (codes or iButtons)

03	#	3 Digits	#	3 Digits	#	...	#
		(Enter 1 st Index Number)			(Enter 2 nd Index Number)		

15. Enable/ Disable Passage Mode

15	#
-----------	---

Note: When Passage Mode is enabled, the lock will stay in unlock after first person enter a valid user code. Re-enter a valid user code to lock back.

16. Enable/ Disable LED blink light

18	#
-----------	---

17. Enable Daytime Saving

31	#
-----------	---

18. Disable Daytime Saving

32	#
-----------	---

19. Add One Time Service codes (up to 10)

33	#	1-8 Digits	#	1-8 Digits	...	1-8 Digits	#	
		(Enter 1 st code)			(Enter 1 st code)			(Enter Last code)

20. Enable Keypad backlighting

34	#
-----------	----------

21. Disable Keypad backlighting

35	#
-----------	----------

22. Delete one User or multiple Users

44	#	3 Digits	#	...
-----------	----------	-----------------	----------	------------

(Enter Index Number)

23. Set Automatically unlock Time

63	#	HHmm	#
-----------	----------	-------------	----------

(Enter Hour/Minute)

Note: The lock will automatically unlock the door everyday at assigned time.

24. Enable Auto-unlock Function

64	#
-----------	----------

25. Disable Auto-unlock Function

65	#
-----------	----------

26. Set Automatically lock Time

66	#	HHmm	#
-----------	----------	-------------	----------

(Enter Hour/Minute)

Note: The lock will automatically lock the door everyday at assigned time.

27. Enable Auto-lock Function

67	#
-----------	----------

28. Disable Auto-lock Function

68	#
-----------	----------

29. Enable/Disable Temporary Lockout All The Users Function

99	#
-----------	----------

Note: Enable the Lockout mode will freeze the lock at its current state (Lock or unlock), temporarily disable all the users' code and iButton keys until the 99 code reentered.